

INSTALLATION INSTRUCTIONS: Honda Pioneer Windshield

It is recommended that bolts remain "hand tight" until all bolts are installed.

CONTENTS:

- Windshield with hand operated wiper
- 5- 1 3/4 " Plastic Tube Clamp with "U" nut
- 2- 2" Plastic Tube Clamp with "U" nut
- Bolt Kit

STEP 1



- Place the provided Plastic Tube Clamps in the approximate locations indicated here.
- Pay particular attention to where the 2" clamps need to be placed.

STEP 2



- Set the windshield in place.
- Secure the windshield with the provided 1/4-20 x 1" button head bolts with a flat washer.
- Once all the bolts are in place, adjust the windshield so that the sides and top are all touching the tube and tighten all the bolts.