



**INSTALLATION INSTRUCTIONS: RZ Rear
Receiver Hitch Bracket 439-0303-03**

STEP 1



- Remove two rear bolts holding the engine shroud.

STEP 2



- Loosen two side bolts holding the engine shroud.

STEP 3



- Slide bracket between frame and engine shroud. Reinsert rear bolts and tighten. Tighten side engine shroud bolts.