



INSTALLATION INSTRUCTIONS: Arm Rest





INSTALLATION INSTRUCTIONS: Arm Rest

STEP 1



- Remove the arm mounting bolts indicated here.
- Retain the bolts for installation of arm rests.

STEP 2



- Set the arm rest in place, on the inside of the drive arms.
- Re-insert the factory bolts as indicated here.

STEP 3



- Make any final adjustments for comfort.
- Tighten all bolts