



**INSTALLATION INSTRUCTIONS: Spartan Canopy**

*It is recommended that bolts remain "hand tight" until all bolts are installed.*



**Canopy**



**Bottom Bracket**



**Top Bracket**



**Bolt Kit**



## INSTALLATION INSTRUCTIONS: *Spartan* Canopy

### STEP 1



- Set the Top Brackets on the ROPS as indicated.

### STEP 2



- Insert the provided "U" nuts into the appropriate holes by sliding them over the pre-cut notch in the Bottom Brackets.
- Be sure that the flat side of the "U" nut is facing up as indicated in this illustration. If it is not, the brackets will not couple together properly.

### STEP 3



- Locate the pre-cut holes in the Canopy to be used for installation.



## INSTALLATION INSTRUCTIONS: *Spartan Canopy*

### STEP 4



- Set the Canopy in place over the ROPS while at the same time holding the Bottom Bracket in place. Be sure that the Top bracket is also aligned so that all three holes are aligned.
- Align all corresponding holes and insert the provided bolts with a flat washer.

Note: Some assistance may be required to hold all parts in place while inserting the bolts.

### STEP 5



- Once **all** of the bolts are in place, tighten everything down.