



TEKS PAC KIT

I N S T R U C T I O N S

For more instructions visit SpartanMowers.com or contact your local dealer.

TEKS PAC - KIT PARTS



Figure 1
From left to right: Suspension Elastomers - Soft Grip Knobs - Serrated Nuts - Suspension Bracket - Nuts & Bolts

STEP 1

Raise the seat and remove the two seat elastomers that are located on the crossmember by using a 5/32 or 4mm Allen T-handle and 7/16" wrench.



STEP 2

Install the two rubber bumpers supplied in bolt kit by using the black Allen bolts and 1/4" nuts that were used to hold the seat elastomers on. (do not use the black washers)



STEP 3

Remove the two 3/8" bolts that are centered in the GT Trac plate by using two 9/16" wrenches.



STEP 4

Remove the 3/8" battery bracket nuts with a 9/16" socket. The weight of the battery should hold the bolts in place.



STEP 5

Install suspension bracket and route wiring as shown. Then install the 3/8" nuts back onto the battery bracket bolt and tighten securely. (Letting the deck down will help with getting the bracket into place)



STEP 6

Install the original GT Trac bolts through the GT Trac bracket, suspension bracket and tighten securely with original nuts.



STEP 7

Install the new suspension elastomers as shown. Install the two 5/16" serrated nuts inside the elastomers. Place the soft grip knobs on the bottom of the suspension bracket and tighten the serrated nuts securely (a 1/2" socket will help hold the serrated nuts). You may have to loosen nuts later to adjust elastomers depending on the weight of the operator.



STEP 8

Install the supplied "LB Scale" decal as shown on the left side of the suspension bracket.



