



# RT/SRT BASKET

---

## I N S T R U C T I O N S

For more instructions visit [SpartanMowers.com](https://www.SpartanMowers.com) or contact your local dealer.

# RT/SRT BASKET - KIT PARTS



**Figure 1**  
Basket



**Figure 2**  
Basket Mounts, Nuts & Bolts, & Decal

**NOTE:**

Some air filter breather assemblies could interfere with mounting the basket. To mount basket in this situation, breather assembly may have to be turned. For help turning breather assembly please refer to steps 1 and 2. If air filter breather assembly does not interfere with basket skip to step 3.

**STEP 1**

Remove the (2) air filter housing bolts using a 12 mm wrench and then rotate the housing 90 degrees.



**STEP 2**

After rotating, reinstall the air filter housing bolts and tighten securely.

**STEP 3**

Install the left bracket using the supplied (2) 5/16" carriage bolts and serrated nuts to the left side of the engine cowling. Leave loose for easier installation.



## STEP 4

Install the right bracket using the supplied (2) 5/16" carriage bolts and serrated nuts to the right side of the engine cowling. Leave loose for easier installation.



## STEP 5

Place the basket on top of the left and right brackets and install the supplied (4) 5/16" carriage bolts and serrated nuts. Tighten ALL 5/16" carriage bolts and serrated nuts. Tighten all nuts, including all nuts previously left loose securely at this time.



PARTAN  
MOWERS

## STEP 6

Install the supplied (4) 1/4" carriage bolts and serrated nuts on both sides of the basket and tighten securely.



## STEP 7

Install decals as shown and assembly is complete.



