

Commander/Maverick rear speaker housing instructions:

Hardware included:

- (3) 2" clamps (per side)
- (3) Button head bolts (per side)
- (3) Flat washers (per side)
- (5) Small Christmas tree plugs (per side)
- (1) Speaker housing (per side)

After installing speaker in housing attach front of housing to back of housing using (5) Small Christmas tree plugs provided. Place (3) 2" clamps on R.O.P.S. align clamps with threaded brass inserts in speaker housing start by hand then tighten. Repeat process for other side.