



INSTALL INSTRUCTIONS:

Polaris Ranger 1000 Front Winch Bumper

Safety:

- Ensure that the UTV is safely parked on level ground with the ignition off.
- Wear all appropriate PPE for the following procedures.

Note:

- Leave all hardware loose until the entire assembly is in its final position.



1 x Tube Bumper
1 x Sheet Metal Bumper
1 x Skid Plate
1 x Winch Plate
1 x Accent Plate
2 x Support Brackets
1 x Hardware Kit



INSTALL INSTRUCTIONS: Polaris Ranger 1000 Front Winch Bumper



1.
Remove factory bumper and keep all factory hardware.
2.
Locate Tube Bumper



3.
Attach the bumper to the factory mounting location using Factory bolts and nuts or included 3/8" bolts and nuts.



4.
Locate Winch Plate and supplied hardware.




INSTALL INSTRUCTIONS:

Polaris Ranger 1000 Front Winch Bumper



5.
Attach the Winch Plate to the machine using the 4 factory bolt holes.




6.
Attach the Winch Plate to the bumper using the included 3/8" carriage bolts and nuts.



INSTALL INSTRUCTIONS: Polaris Ranger 1000 Front Winch Bumper



7.
Locate Skid Plate and supplied and factory hardware.



8.
Attach the skid plate to the bumper using the included 3/8" carriage bolts and nuts.

INSTALL INSTRUCTIONS: Polaris Ranger 1000 Front Winch Bumper



9.
Attach the skid plate to the factory holes in the machine using the factory or supplied hardware.



10. Locate the 2 support brackets.



11. Attached with provided bolt and nut to the tube bumper.




INSTALL INSTRUCTIONS: Polaris Ranger 1000 Front Winch Bumper



10.
Locate Sheet Metal Bumper and supplied hardware.



11.
Attach the Sheet Metal Bumper to the Tube Bumper using the included 3/8" carriage bolts and nuts.
12. Attached Sheet Metal Bumper to Support Brackets using included 3/8" carriage bolts and nut.



13. Enjoy!