



ASSIST HANDLE

I N S T R U C T I O N S

For more instructions visit [SpartanMowers.com](https://www.SpartanMowers.com) or contact your local dealer.

RZ SEAT SHOCK - KIT PARTS



Figure 1

Assist Handle, Carriage Bolts, Nylock Nuts, Rubber Bumpers, and Lower Bracket



STEP 1

Set the handle in place as shown.



STEP 2

If the mower is a 2020 or older install the provided rubber bumpers into the holes on lower bracket as shown.



STEP 3

Connect the handle with the lower bracket as shown



NOTE: The view is looking up from underneath the front of the machine of the driver side.

STEP 4

Align the corresponding holes of both pieces of the bracket and secure with the provided carriage bolts and Nylock nuts.



NOTE: Tighten until both brackets meet.

