



KING GRASS STRESS PAD

I N S T R U C T I O N S

For 2020 and Newer Models

For more instructions visit [SpartanMowers.com](https://www.SpartanMowers.com) or contact your local dealer.

HG STRESS PADS - KIT PARTS



MOWERS

Figure 1

- Stress Pad x2
- Soft Grip Knob x4
- Upper Bracket x2
- Lower Bracket Left x1
- Lower Bracket Right x1
- Spur Washers x4
- 5/16" Bronze Washer x4
- Plastic Washer x6
- Allen Head Screws x4
- 5/16" Bolt x2
- 5/16" Carriage Bolt x6
- 5/16" Nylon Lock Nut x4

STRESS PAD ASSEMBLY

STEP 1

Install each stress pad to each upper bracket using the 2, Allen head screws and spur washers for each side.



STEP 2

Install the 5/16" bolt through the upper brackets. Install the bronze 5/16" washer onto the bolt and then install the lower bracket followed by the 5/16" nylon lock nut. Tighten using 2, 1/2" wrenches securely and then back off until the brackets move freely.



PARTAN
MOWERS

STEP 3

Install the 5/16" bronze washer between the upper and lower bracket and then install the 5/16" carriage bolt through the square hole, bronze washer and out of the slotted hole, followed with the plastic washer and then the soft grip knob. Tighten securely by hand.



INSTALLING THE STRESS PADS

STEP 4

Install the 5/16" carriage bolt through the lower hole on the inside of the grab bar, followed by installing the black plastic washer, lower stress pad bracket and 5/16" nylon lock nut. Tighten using 2, 1/2" wrenches, then back off until bracket slides up and down freely.



STEP 5

Install the 5/16" carriage bolt through the upper hole on the inside of the grab bar. Install the black plastic washer onto the 5/16" carriage bolt and then install the soft grip knob and tighten securely by hand.



STEP 6

Repeat these steps on the remaining side left to be done.

